

IMPORTANT TIPS FOR THE INSTALLATION OF A RETRÖ FITTINGS SET

1. BE SURE TO CHECK THE WEIGHT CAPACITY OF THE WALL

- Be sure to check the weight capacity of the wall prior to the installation. A “standard” door weight is between 20-50 kg depending on the door size, but this of course depends on what kind of door you use. The wall structure and the fixings must carry the weight of the door and the track mechanism.
- When fixing to stone walls, use the appropriate wall plugs. When fixing to drywall at least some of the screws must be fixed to the frame post.
- To make sure that the drywall’s capacity is enough, you can install “a support strip” underneath the brackets, which can be installed to the wall with panel anchors.

2. BE EXACT WITH YOUR MEASUREMENTS

- First you must carefully measure the tracks place on the wall according to the installation instructions included in the Retrö fittings set. To ensure that the track is straight use a leveller.
- Make sure that the holes for the hanger screws are drilled in the right places according to the instructions.
- Make sure that the door slides smoothly the entire track length.

3. AND ALWAYS REMEMBER SAFETY FIRST

- The installation of the track mechanism is safe, if you follow the installation instructions. Use the anti-jump blockers to make sure that the door stays on the track. Remember to tighten the screws and nuts occasionally, as the doors movement causes them to loosen a little over time. Please note that the customer is responsible for any product damages caused during the installation.

Have a great installation!

helaform®





